




300 N. Oakley Blvd.
Chicago, IL 60612 USA
Phone 312-226-2473
FAX 312-226-2480
sales@cozyproducts.com
www.cozyproducts.com

TOASTY TOES

Instructions

Part # TT



OPTIONS: Use product with raised-pattern side facing out. There are three positions for use.

1. **Flat.** When using the Toasty Toes in flat position on the floor (for resting your feet only; never stand fully on unit) - position the Toasty Toes in front of you making sure that all optional folding stands are folded flat inside the back of the unit, and use as a footrest while seated.
2. **As a Footrest.** Turn the Toasty Toes upside down and place it flat on a surface with the cord protruding toward you. Take hold of the large angled folding stand closest to you (flap pair A, shown above). Pull it out till it stands up at a right-angle. Give it a slight downward push to lock it into place in this position. Repeat with the identical flap positioned opposite. Turn over Toasty Toes and place where it is convenient for you to rest your feet on the top, which will now be at a gentle ergonomic angle for best support and comfort.
3. **As a vertical Heat Panel** (feet will not be resting on it). Turn the Toasty Toes upside down and place it flat on a surface with the cord protruding toward you. Take hold of the long, narrow folding stands furthest from you (flap pair B, shown above). Pull both out till they are at right-angles to the Toasty Toes heat panel. You will feel each one 'click' into position. Turn Toasty Toes right-side up, resting slightly backwards onto these stabilizing stands, and position it vertically near your feet.

HEAT SETTINGS: On the control dial, select OFF, LOW or HIGH at your preference. The indicator light on the dial will glow when the product is on. When in use as a vertical panel, HIGH will be most effective at keeping your immediate area warm.

CAUTION: Never place objects other than your feet on Toasty Toes, including household pets, cloth, chairs, desks, etc. This could cause overheating or puncturing of the product. Allow the heater to cool down before handling, touching or moving.

CLEANING: Unplug unit and wipe with a damp cloth.

ELECTRICAL SPECIFICATIONS: 120 VAC 60Hz 105W
--

IMPORTANT: READ BEFORE USE

CAUTION: Toasty Toes is designed for use ONLY with 110/120 volt power supply such as USA and Canada.

DO NOT use Toasty Toes with 220/240 volt electric supply such as is common in UK, Europe & other countries outside the USA.

This appliance has a polarized plug. One blade is wider than the other. To reduce risk of electric shock, this plug is intended to fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

WARRANTY: This product is warranted against defects in materials and workmanship for a period of six months from the shipping date. At the option of Cozy Products, we will either replace or repair the defective unit. For support, contact Cozy Products: 800.662.5021 customerservice@cozyproducts.com

WARNING: Take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to suitability or fitness of these devices for any specific application. While product includes an overtemperature regulator, misuse may cause failure, damaging the product, mounting surface or work area. Use in a dry area; avoid exposure to moisture. Mount free from materials that hinder the transfer of heat. Do not drape or cover product with any material. Always allow heat to escape. Protect from puncture. Turn off when not in use. Use caution as you would with any hot product, especially if you have any issues with loss of feeling in the areas affected by the heat.

HOW IT WORKS: Toasty Toes is designed to warm up to a safe temperature to keep your legs and feet comfortable where you sit or stand. The heat is thermostatically controlled. Toasty Toes promotes better circulation and helps keep away chills and drafts. Toasty Toes uses just 105 watts, significantly reducing energy consumption and fire risk compared with typical space heaters.